


KINGSTON BED SET

Model #1503-460 Full Size - Metal Bed Set Model #1503-500 Queen Size - Metal Bed Set Model #1503-660 King Size - Metal Bed Set

Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. Customer Service Phone Number: 502-562-0000



STEP 1

Begin assembly by attaching each Leg Extension (J) to the bottom of each post on the Headboard Panel (H) by fitting in place and fastening with 2 Allen Bolts (A) & 2 Flat Washers (E) per each side. Do not fully tighten bolts.

STEP 2

Insert the Leg Brace (K) between each Leg Extension (J) by aligning holes and securing from the outside with 1 Allen Bolt (B) & 1 Flat Washer (E) per each side. Tighten all bolts from Steps 1 & 2 using the Allen Wrench (F) that has been provided.

STEP 3

Attach the Bed Frame (*Not Included) to each Leg Extension (J) using 2 Allen Bolts (B) from the backside, 2 Flat Washers (E) & 2 Hex Nuts (D) from the front per each post. Tighten all bolts.

STEP 4

Finally attach the Bed Frame to each post on the Footboard (L) by aligning holes and securing with 2 Allen Bolts (C) & 2 Flat Washers (E) per each side. Tighten all bolts. The assembly is now complete.

CARE & MAINTENANCE: The touch of a soft cloth is all the maintenance the finish will ever need. Please do not use harsh or abrasive cleaners for polishing, as they may cause damage to the finish. Periodic checks are recommended to make sure that all bolts, screws and nuts are securely tightened.