



*Live life Comfortably.™*



# USE AND CARE GUIDE

## Sears Madeline Umbrella - Red

Product Code: D71 M20927

UPC Code: 7 22938 11292 0

Date of Purchase: \_\_ / \_\_ / \_\_

La-Z-Boy® is a registered trademark of La-Z-Boy Incorporated and is used under license to BJI, Inc.

© 2015 La-Z-Boy Incorporated.

# Thank you for your purchase

---

## THANK YOU FOR YOUR PURCHASE!

We are pleased that you have chosen Sears for your outdoor furniture purchase. We hope that you enjoy the unmatched quality, comfort, and style of your new patio set. Every piece is meticulously considered all the way down to the smallest details, exclusively for you, by our world class design team. We know you have a choice when it comes to your patio furniture needs, so from our team to yours, thank you for letting us be a part of your outdoors.

## Table of Contents

---

<b>Table of Contents.....</b>	<b>2</b>
<b>Safety Information .....</b>	<b>3</b>
Set up your item properly .....	3
Examine your item .....	3
<b>Warranty .....</b>	<b>3</b>
What is covered .....	3
What is not covered .....	3
<b>Care and Maintenance .....</b>	<b>4</b>
<b>Pre-Assembly .....</b>	<b>5</b>
Planning assembly.....	5
Package contents .....	6
<b>Assembly Instruction .....</b>	<b>7</b>
<b>Customer Service .....</b>	<b>11</b>

## Safety Information

### SET UP YOUR ITEM PROPERLY

- Ensure that all parts are assembled properly and fully tightened as per the instructions.



**CAUTION:** Read all of the instructions in this manual before you begin assembly. Failure to do so may result in faulty assembly and potential injury!

### EXAMINE YOUR ITEM

- Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be retightened fully before additional use.



**WARNING:** 1. Never use umbrella without an umbrella base and matching table.  
2. Never use umbrella in high wind conditions. Damage to umbrella and / or table can occur.  
3. Always leave umbrella in down position when not in use.

**NOTICE:** Table and umbrella base are only for instruction reference and are sold separately.

## Warranty

**THIS IS A RESIDENTIAL WARRANTY AND DOES NOT APPLY FOR COMMERCIAL USE.**

**1 YEAR WARRANTY FOR FRAME.**

### WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for 1 year.

### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use.

Discoloration or fading of the finish or fabrics as a result of chemicals or spills is not covered.

Glass table top breakage and corrosion or rusting of hardware are not covered.

In addition, purchase parts are not covered under this warranty.

Proof of purchase (dated register receipt) is required for warranty claims.

## Warranty (continued)

---

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-866-391-4868 or visit [www.bjifurniture.com](http://www.bjifurniture.com).

## Care and Maintenance

---

- Do not allow water to build up in frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. DO NOT use janitorial or alcohol based cleaners. Some cleaners may be marked as natural, but some ingredients can cause discoloration or have adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- Cushions, slings, and/or an umbrella may be cleaned by hand with a solution of soap and water with a clean water rinse. Never machine wash as this will result in shrinking or damage. After cleaning, tip on end and allow to drip dry. Never use a commercial or home dryer to tumble dry fabric goods.
- Treat frames with liquid wax for maximum protection against UV rays and /or salty, damp air.
- Umbrella should be closed when not in use. Umbrella should be removed and stored in the event of wind, rain, hail, sleet, snow, or any other inclement weather. To prevent damage to your table, always use an umbrella base with your umbrella. Store indoors during winter months.
- Use and operation: To prolong the life of your outdoor furniture, cover when not in use. Store indoors during winter months.

# Pre-Assembly

---

## PLANNING ASSEMBLY

PLEASE READ COMPLETE USE AND CARE GUIDE PRIOR TO ASSEMBLY!


Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts on a nonabrasive surface to avoid scratching. It takes about 5 minutes for 1 person to complete all the assembly.



**NOTE:** More than one person may be required to complete the assembly of this product.

## Pre-Assembly (continued)

### PACKAGE CONTENTS



Part	Description	Quantity
A	Plastic Cap	1
B	Umbrella W/crank handle	1
C	Support Tube	1


## Assembly Instruction

---

### 1 Attaching the plastic cap

**NOTICE:** Do not open the umbrella.

- Attach the plastic cap (A) to the umbrella (B).




## Assembly Instruction (continued)

### 2 Inserting the support tube

**NOTICE:** Table and umbrella base are only for instruction reference and are sold separately.

- Place the umbrella base under the center of the table.
- Loosen the knob on the umbrella base.
- Insert the support tube (C) through the hole in the table and into the umbrella base.
- Tighten the knob on the umbrella base.






## Assembly Instruction (continued)

### 3 Attaching the umbrella

- Before opening the umbrella (B), turn it upside down and shake gently to separate ribs.
- Carefully screw the umbrella (B) into the support tube (C) until attached tightly.



## Assembly Instruction (continued)

### 4 Opening the umbrella

- Slowly turn the handle of the umbrella (B) until the umbrella is completely open.
- Umbrella is ready for your enjoyment.



**WARNING:** 1. Never use umbrella without an umbrella base and matching table.  
2. Never use umbrella in high wind conditions. Damage to umbrella and / or table can occur.  
3. Always leave umbrella in down position when not in use.





Please refer to part number when reordering

Questions, problems, missing parts? Before returning to the store,  
call our Customer Service

8 a.m. - 5 p.m., EST, Monday-Thursday

8 a.m. – 4 p.m., EST, Friday

**1-866-391-4868**

Made in/ Hecho en CHINA

Distributed by Sears, Roebuck and Co., Hoffman Estates, IL60179

See our extensive assortment of outdoor living products on-line

at [www.sears.com](http://www.sears.com) and [www.kmart.com](http://www.kmart.com)

Retain this manual for future use.