

### To connect the water supply to the rear of your refrigerator:

- 1 Ensure that the refrigerator is not plugged in.
- 2 Flush the supply line until water is clear by placing the end of the copper tube in a sink or bucket and opening the shut-off valve. 3 Remove the plastic cap from the water valve inlet at the rear of
- your refrigerator. Discard the cap. Slide the brass compression nut, then the ferrule (sleeve) onto
- 5 Push the copper tube into water valve inlet as far as it will go 6 Slide the ferrule (sleeve) into valve and finger-tighten the
- compression nut onto valve. Tighten another half turn with a
- Secure the copper tube to your refrigerator's rear panel with a steel clamp and screw (see illustration).
- refrigerator as shown. Arrange coiled tubing to avoid vibration or wear against other surfaces. 9 Open water supply shut-off valve and tighten any connections that leak
- The ice maker's fill valve may operate noisily if the household water supply is shut off.
- After ensuring no water leaks exist at any connection, be sure to check for leaks again in 24 hours. • See your Use & Care Guide for detailed information about setting up and operating the Ice &

# 4 Place In Permanent Position

If possible, use a hand truck to position the refrigerator directly in front of its cabinet enclosure. Be careful not to move the refrigerator beyond its water supply (copper tubing) connections.

Plug in the power cord, and push the refrigerator

If you are installing your refrigerator without connecting it to a water supply, make sure the ice maker's power switch is turned Off (see the Use &

## **5** Level Refrigerator & Adjust Doors (if necessary)

### Guidelines for final positioning of your refrigerator:

- All four corners of the cabinet must rest firmly on the floor.
- The cabinet should be level at the front and rear. The sides should tilt 1/4-inch (6 mm) from front to back (to
- ensure that doors close and seal properly) Doors should align with each other and be level.

#### To level the cabinet using the front rollers:

- 1 With both doors closed, unfasten right and left side clips of toe grille from bottom hinge groove Open both doors. Press firmly on top of toe grille until top of toe grille pops off. Pull toe grille outward toward your body and off of lower hinges.
- 2 Close the doors and use a flat-blade screwdriver or 3/8 inch socket wrench to raise or lower the front rollers. (See
- 3 Ensure both doors are bind-free with their seals touching the

# To level the doors using the adjustable lower hinge (Type 1

- 1 Before leveling either door, remove set screw that locks door height into position. (The door cannot be adjusted without set screw removed.)
- 2 If the refrigerator door is lower than the freezer door, raise the refrigerator door by turning the adjustment screw clockwise using a 7/16 inch wrench. (See illustration 3.)
- 3 If the freezer door is lower than the refrigerator door, raise the freezer door by turning the adjustment screw clockwise using a 7/16 inch wrench. (See illustration 3.)
- After leveling, verify door stop contacts lower hinge and top of door does not contact upper hinge through full movement of door (from fully closed to fully open). (See illustration 4.) Reinstall set screw, locking the door height.
- 6 To replace the toe grille, open both doors. Slide left and right sides of toe grille over lower hinges of refrigerator. While pushing toe grille firmly against cabinet, fasten bottom clips of toe grille to cabinet. Fasten top clips to cabinet. Close the doors. Fasten right and left side clips into groove of bottom hinge

# 5

- 3

Operation problems are possible if any of the installation tasks are not completed. Here is a list of things to check for:

Other possibilities to check:

# 8

### **Doors**

- sides
- Doors are level

### Leveling

- 1/4" (6mm) front to back
- □ Refrigerator is level, side to side and tilted □ Toe grille is properly attached to
- refrigerator
- □ Cabinet is sitting solid on all corners

# **Electrical Power**

- Not satisfied with the installation of your refrigerator?  $\triangleright$  Please contact the store you purchased it from.



t

3

CAUTION

Shifting the refrigerator from side

Do not block the toe grille on the

lower front of your refrigerator. Sufficient air circulation is essential

to side may damage flooring.

for proper operation.

to Ice Make

Brass

Water Valve — Bracket

(Include enough tubing in loop to allow moving refrigerator out for cleaning.)

# (continued)


#### To level the doors using the adjustable lower hinge (Type 2 without set screw)

If the refrigerator door is lower than the freezer door, raise the refrigerator door by turning the adjustment screw clockwise using a 7/16 inch wrench. (See illustration 3.) 2 If the freezer door is lower than the refrigerator door, raise the freezer door by turning the

adjustment screw clockwise using a 7/16 inch wrench. (See illustration 3.) After leveling, verify door stop contacts lower hinge and top of door does not contact upper

hinge through full movement of door (from fully closed to fully open). (See illustration 5.)

4 To replace the toe grille, open both doors. Slide left and right sides of toe grille over lower hinges of refrigerator. While pushing toe grille firmly against cabinet, fasten bottom clips of toe grille to cabinet. Fasten top clips to cabinet. Close the doors. Fasten right and left side clips into groove of bottom hinge.



# **6** Problems? Try These Suggetions

Is the refrigerator's power cord plugged in?

Is the refrigerator connected to the household water supply?

• If you had to remove the refrigerator and freezer doors, did you reattach water and power connectors at the door hinges? (See the Use & Care Guide for detailed instructions on removing and replacing doors.)

Is the ice maker power switch turned **On**?

• Is the power to the receptacle turned on?

 Is the water filter above the fresh food compartment fully seated (see Use & Care Guide for details)? If you still have operation problems after checking these suggestions, please see the "Solutions To Common Problems" section in your Use & Care Guide.

### What's Next?

Congratulations. You are ready to begin enjoying your new refrigerator.

 To become aware of important safety instructions and learn how to operate your refrigerator, please read the entire Use & Care Guide.

 You may want to start with the "Normal Operating Sights & Sounds" section of the Guide to learn more about what to expect during typical operation.

 Please register your product. You can register online at www.electroluxusa.com. or you can simply send in the Registration Card.

And thank you for choosing Frigidaire.

## ☑ Installation Checkoff List

#### Ice Maker

refrigerator

Door seals completely to cabinet on all

- □ House power turned on
- □ Refrigerator plugged in

□ No water leaks present at all connections - recheck in 24 hours

□ House water supply connected to

- □ Ice Maker is turned ON.
- □ Ice & Water Dispenser operates correctly
- □ Front filter must be flush with filter housing (some models)

### **Final Checks**

- □ Shipping material removed
- □ Fresh Food and Freezer temperatures set
- □ Crisper Humidity controls set
- □ Registration Card sent in