



## Quick Install Guide


### TABLE OF CONTENTS

COMPONENTS.....	3
BATTERY CHARGING.....	6
WI-FI SETUP .....	7
INSTALLATION.....	7
HARDWIRING .....	8
ANSWERING A CALL.....	9

With Ring, you're  
**always home.**

2


### FRONT



1. Wide Angle HD Camera
2. Microphone
3. LED Ring
4. Push Button
5. Speakers

3


### BACK



6. Setup Button
7. Micro USB Charging Port
8. MAC Address

4

### MOUNTING BRACKET



9. Doorbell Wire Terminals
10. Mounting Hooks
11. Wire Management Hooks

5

## BATTERY CHARGING

Charge your device using a USB-compatible wall charger or laptop. To ensure your device is fully charged, charge the device prior to Wi-Fi setup and installation.

## LED RING LIGHTING SEQUENCES

Battery Charging		LED Ring spins blue, then white.
Battery Charging Complete		LED Ring stays fully lit blue.
Call Initiated		LED Ring spins blue.
Call Connected		LED Ring stays fully lit blue.
Hardwired		LED Ring stays dimly lit white.
Setup Mode		LED Ring spins white.
Software Update		LED Ring blinks white.
Factory Reset		LED Ring blinks blue.

6

## WI-FI SETUP



Download the Ring app from the App Store or Google Play. Open the Ring app and select Setup Device. Follow the in-app instructions to set up your Ring.

## INSTALLATION

1. Remove doorbell button and power off your transformer (for wired installation only).
2. Line up the mounting bracket using the provided mounting level.
4. Install the mounting bracket using the provided screwdriver bit, handle and drill bit.  
**Brick - use concrete screws and anchors**  
**Concrete - use concrete screws and anchors**  
**Stucco - use concrete screws and anchors**  
**Wood - use wood screws**  
**Vinyl - use wood screws**
5. Remove the mounting level.
6. Connect your doorbell wiring to the terminal screws located on the mounting bracket (for wired installation only).
7. Place the device on the mounting bracket.
8. Tighten the security screws at the bottom of the device using the proprietary screwdriver bit. **Please do not over-tighten the security screws.**
9. Provide power back to your transformer (for wired installation only).


7

## HARDWIRING REQUIREMENTS

If powering off doorbell wiring, the wiring must be connected to a transformer and a doorbell with a voltage of 8VAC - 24VAC to ring your doorbell chime.

If your chime is electronic, you may need to install a diode, which is commonly found inside your current doorbell button, or check with your doorbell manufacturer.

Connect the diode to the terminals with the arrow on the diode facing towards the doorbell chime as shown below.



8

## ANSWERING A CALL



Mute Volume



Disable Microphone



End Call



Call Zoom

To disable notifications for your Ring device, select it from "My Devices". Select "Device Settings" and toggle notifications off.

9

## CUSTOMER SUPPORT

For additional product information and helpful tips, check out our support forum at:

[ring.com/help](https://ring.com/help)

For immediate assistance, please call us at:

**DOMESTIC:** 1-800-656-1918

**INTERNATIONAL:** +1 310-929-7085

7 days a week  
9 a.m. to 5 p.m. PST.



1523 26th St.  
Santa Monica, CA 90404



Hereby, Bot Home Automation, declares that this consumer electronic is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at [www.ring.com/DoC.pdf](https://www.ring.com/DoC.pdf).

Protect the device from direct sunlight. Install the device at dry locations and protect it against rain and humidity. The device may not get contact to salt water or other conductive liquids. The device must be charged only within a building in a dry state.